





Real time mode (second indicator running)

## TIME SETTING

While in real time mode, press MODE 3 times to launch the time setting mode (second indicator flashing). Adjust the flashing item by pressing START. Press RESET to select other items. Holding down START changes the number at high speed. When finished setting, press MODE to return to real time mode.

While adjusting the hour, choose "A" / "P" for 12-hour (AM/PM) indication, or "H" for 24-hour indication.

## **STOPWATCH**

While in real time mode, press MODE once to launch the stopwatch (ST) mode.

Press START for starting/stopping the stopwatch. Press RESET to clear the stopwatch to all zeros.

## **ALARM**

While in real time mode, press MODE twice to launch the alarm ("AL") mode.

Press RESET to adjust the alarm time. Adjust the hour by pressing START. Press RESET to select the minute and START to adjust it. Holding down START changes the number at high speed. When finished setting the alarm, press RESET to confirm and press MODE to return to real time mode.

Important: Besides setting the alarm time, the alarm should be switched on in order to beep. Switch the alarm ( W )





and *hourly chime* () functions on/off by pressing START while in alarm mode.

When the alarm beeps, press START or RESET to stop it, or press MODE to switch the **snooze** function on/off. With the snooze function on ( flashing), the alarm will beep again in 5 minutes.

## **HOURLY CHIME (SIGNAL)**

Switch the hourly chime function on/off by pressing START while in alarm setting ("AL") mode. visit in indicated when it's on.